

MONOFORO/ MONOCOMANDO

- a. Avvitare tubetti flessibili (1) e tirante (2) al rubinetto
- b. Svitare pomolo (3) del saltarello ed inserire la parte superiore dell'asta da sotto, tranne MiròMix (4), riavvitare pomolo (3).
- c. Inserire e posizionare alla base del corpo la basetta e la guarnizione (6+5) ove di serie.
- d. Posizionare il rubinetto sul foro del piano, nella parte inferiore inserire guarnizione sagomata e flangia nel tirante (2) e stringere con il dado di fissaggio (7).
- e. Avvitare la seconda parte dell'asta (8) e unirla allo scarico tramite lo snodo (9)
- f. Collegare i tubetti flessibili ai punti di erogazione del muro.

MONOBLOC AND SINGLE LEVER MIXER

- a. Screw the flexible tails (1) and the fixing tube (2) to the faucet
- b. Unscrew the knob (3) of the rod and insert the upper part of the rod in the lower part of the body , with the only exception of MiròMix (4).Screw again the knob (3)
- c. Insert the flange and the washer (6+5) to the base of the faucet (where it is supplied)
- d. Place the tap on the hole of the plane and, from the under side, insert the washer and the flange through the fixing tube (2). Tighten with the fixing nut (7).
- e. Screw the under part of the rod (8) and connect it to the waste through the brass nut (9)
- f. Connect the flexible tails to the wall.

